

FLOW E-FIN 2.0

QUICKSTART



JOBE'S 

1. FUNCTIONS

„PADDLE“ - The E-fin enhances each paddle stroke at a preset level.

„DRIVE“ - The E-fin speeds up as you push the remote slider up, push down to reverse.

„CRUISE“ - The E-fin drives the board at a constant level selected on the remote.

Press the power button to switch between the modes.



2. ASSEMBLY

1. Select the appropriate fin box adapter for your SUP and attach it to the E-fin with the provided screws.
2. Now mount the E-fin on your SUP.
3. Secure the E-fin to your SUP with the provided fin safety leash.
4. Attach the remote control to your paddle at chest height.
5. Secure the remote control on your paddle with the provided remote safety leash.

3. POWERING ON AND OFF

The E-Fin - The E-fin automatically switches on as soon as it enters the water and automatically switches off when it's removed from the water.

The remote - Press the button once to turn it on, hold it for 4 seconds to turn it off. The remote automatically switches off 10 seconds after the E-fin switches off.



Make sure the charging port is completely dry before recharging.



WARNINGS



Warning: Never drive through seaweed, mud or silt. This can block the propeller. If something gets into the propeller, take the E-fin out of the water, dry it completely and then remove the foreign object with a tool. Never put your fingers into the propeller.



Warning: Always make sure there is enough draft (> 0.5 m) before you put the board in the water with the E-fin attached. In the water, you should always keep an eye on shallows and maintain the minimum distance between the E-fin and the bottom.



Warning: Do not open or tamper with the electronics housing. You could get an electric shock. This would also invalidate the warranty.



Warning: Always make sure that the screws of the adapter are tight and that the E-fin is correctly inserted into the fin box.



Warning: Make sure that you do not get your fingers, hair or clothing into the propeller or other moving parts.



Warning: Always keep the E-fin out of reach of babies and small children.



Warning: Make sure the charging port is dry before charging.

Ride responsibly and respect the people around you.

COMPLETE MANUAL

Scan the QR code for the complete manual.

Scan de QR-code voor de volledige handleiding.

Scannen Sie den QR-Code für das vollständige Handbuch.

Scannez le code QR pour consulter le manuel complet.

Escanee el código QR para ver el manual completo.

Scansiona il codice QR per il manuale completo.

Zeskanuj kod QR, aby uzyskać pełną instrukcję obsługi.

Naskenujte QR kód pro kompletní návod.

Naskenujte QR kód pre kompletný návod.

Skenirajte QR kod za potpuni priru nik.

Skannaa QR-koodi nähdäksesi koko käyttöohjeen.

Tüm kullanım kılavuzu için QR kodunu tarayın.

Skann QR-koden for fullstendig brukermanual.


Σαρώστε τον κωδικό QR για το πλήρες εγχειρίδιο

لمالكها لي لدلدا ىلع عالطاللة عي رسلا ةباجتسالال زمر حسام

扫描二维码查看完整说明书



www.jobesports.com/manuals



#JOBEMOMENTS

